

SOPLAIR

EXTERNAL INSULATION



RANGE DE LUXE **ISOPLAIR**

Our luxury ISOPLAIR range is made from a breathable, fully waterproof textile shell that includes a multi-layer insulation set. With its **10 technical layers**, our coverings act as a real external insulation in summer and winter, giving you maximum protection against temperature variations.

Our insulated cover will improve your comfort and permanently eliminate condensation inside your vehicle. Totally opaque, it will protect your privacy. Its front opening will allow you to let the light in when you are parked without having to remove your protection. They are **available for all types of motorhomes**: profiles, A-Class, but also panel vans.



KEY POINTS



PROTECTION

Against extreme temperatures in summer and winter. Protects against heat loss in winter when the heating is on.



OPAQUE

Preserves your privacy and prevents UV rays from entering the vehicle.



FIXING

By bellows on the doors for semi integrated vehicles and by rivets for integrated vehicles



ZERO CONDENSATION

Eliminates condensation and fogging.

Semi integrated and panel van cabins

VEHICLE MODEL	REFERENCE
Jumper/Boxer/Ducato from 1994 to 2006	720598
Jumper/Boxer/Ducato since 07/2006	720612
FORD Transit from 1994 to 2014	720611
FORD Transit since 2015	720643
RENAULT Master, opel movano, nissan interstar 1998 to 2010	720605
RENAULT Master, opel movano, nissan NV 400 since 04/2010	720602
MERCEDES Sprinter from 1995 to 2006	720593
MERCEDES Sprinter since 06/2006	720601
IVECO Daily I & II from 2000 to 2013	721366
IVECO Daily since 2014	720610
OTHER MODELS ON REQUEST*	



Panel van cabin

VEHICLE MODEL	REFERENCE
Jumpy II /Scudo II/Expert III/ Pro Ace 2007-2016	720794
Jumpy III /Scudo III/Expert III/ Pro Ace II since 2016	720795
FORD Custom Transit & Tourneo since 2012	720796
MERCEDES VITO from 2003 to 2014	720797
MERCEDES VITO III since 2014	720798
RENAULT TRAFIC II/Vivaro I/Primastar from 2001 to 2014	720631
RENAULT TRAFIC III/Talento II /NV300 / Vivaro II since 2014	721631
VOLKSWAGEN T4	720628
VOLKSWAGEN T5 / T6	720629
OTHER MODELS ON REQUEST*	

Fully integrated cabin

VEHICLE MODEL	REFERENCE
Isoplair Intégral*	Isoplair Integral vehicle
OTHER MODELS ON REQUEST*	

* Subject to technical feasibility.

ISOPLAIR
FOR SEMI INTEGRATED
VEHICLE



Front opening



Installation by bellows in doors
for semi integrated model



Storm reinforcement

ISOPLAIR
FOR SEMI INTEGRATED
VEHICLE



Front opening



Rivet system for fully
integrated vehicle



Stainless steel pressure rivets