

USE THE UNIVERSAL A-MEASUREMENT METHOD TO CHOSE THE RIGHT SIZE FOR YOUR FULL AWNING



- Make sure your caravan is parked on level ground
- Take along a sufficiently long piece of string
- Start at point A, pass it through the awning rail, and work your way to point B
- Then measure your string with a tape measure

HOW BIG IS YOUR AWNING ?

Size	2	3	4	5	6	7	8	9	10
A-measurement in metres	6.75 - 7.00	7.00 - 7.25	7.25 - 7.50	7.50 - 7.75	7.75 - 8.00	8.00 - 8.25	8.25 - 8.50	8.50 - 8.75	8.75 - 9.00
11	12	13	14	15	16	17	18	19	20
9.00 - 9.25	9.25 - 9.50	9.50 - 9.75	9.75 - 10.00	10.00 - 10.25	10.25 - 10.50	10.50 - 10.75	10.75 - 11.00	11.00 - 11.25	11.25 - 11.50